


Updating the PIR-1 Firmware

Last Modified on 08/09/2023 6:24 pm EDT

When connecting a **PIR-1** to URC Accelerator or Complete Control Program software, it requires a Firmware Update, however, when the steps are followed, the update fails every time.

The following article details the process to **update the firmware** of the **PIR-1** Professional IR learner.

Note: This article details a Windows 10 OS installation



Updating the PIR-1 Firmware

Symptom: When connecting a PIR-1 to URC Accelerator or Complete Control Program software, it requires a Firmware Update, however, when the steps are followed, the update fails every time.

Reason: The chipset within the PIR-1 needs to be updated to work with the latest version of URC software.

Solution:

Here are the steps to resolving this issue:

1. Go to **FTDI** (chip manufacturer) website: www.FTDIchip.com
2. In the left-hand column select **DRIVERS**
 - a. In the **DRIVER** section, select **D2XX Drivers**

3. In the software chart, find the **Windows** section

a. Select either **X86 (32-Bit)** or **X64 (64-Bit)** based on your PC processor type


Currently Supported U2XX Drivers:

[Subscribe to Our Driver Updates](#)

Operating System	Release Date	Processor Architecture					Comments
		X86 (32-Bit)	X64 (64-Bit)	ARM	MIPS	SH4	
Windows (Desktop)*	2021-07-15	2.12.36.4	2.12.36.4	2.12.36.4A*****	-	-	WHQL Certified. Includes VCP and D2XX. Available as a setup executable . Please see the Release Notes and Installation Guides .
Windows (Universal)****	2021-11-12	2.12.36.4U	2.12.36.4U	-	-	-	WHQL Certified. Includes VCP and D2XX.
Windows RT	2014-07-04	1.0.2	-	1.0.2	-	-	A guide to support the driver (AN_271) is available here


4. **UnZip** downloaded file to a designated location/folder

5. Go to **Windows Device Manager on your PC**



a. Select the **COM Port (Ports)** section


b. Right-click on **USB Serial Port**



c. Select **Update Driver** for USB Serial Adaptor

d. Select **BROWSE** for **FOLDER** and direct Device Manager to the previously designated folder for the file. Install the new driver.

e. Verify that the correct driver is now installed:



6. Open URC software and try the **PIR-1Firmware Update** again

Thanks to Hopeton A. Barnett in URC Tech support for this tip.

Additional Information & Resources:

To learn more about HDA products and programming, please see the [HDA Programmers Guide](#) or the Accelerator 3 online [Programming Guide](#).

URC