

TRC-1280: Troubleshooting

Last Modified on 05/10/2016 1:08 pm EDT

How to troubleshoot the TRC-1280

If the TRC-1280 is not connecting do the following;

1. **Press and hold** main and select to bring up the settings menu.
2. Navigate to the **wifi network tab** on the settings screen and then click settings. A wireless network search is done for you. Select your network.
3. Add it to preferred list below and type in your password and click enter when done.
4. In Total Control Step 6:Network Setup (URC Device), select the TRC-1280 and click discover (refresh button), then click assign when it appears in the right side window. Remote must be in cradle to download to it or be awake.



MB

If you require any additional information or have any questions, please do not hesitate to contact our **technical support** team at **914-835-4484**.
