

Teaching Dish Network Boxes to Work with URC MX Remotes

Last Modified on 06/17/2016 3:35 pm EDT

Dish Network Boxes require a specified IR address/ID. If a user adds additional Dish Network remotes to an already installed system, the URC IR frequency must be re-addressed.

To learn a URC MX remote frequency, follow the steps below:

1. **Click "Menu"-6-1-8 on the Dish remote and select/highlight the IR address.**
2. **Hit the record button on the URC MX Remote.** This teaches the Dish network box the **IR frequency** the URC MX remote is using.

as

If you require any additional information or have any questions, please do not hesitate to contact our **technical support** team at **914-835-4484**.
