

Lost Program After Changing Batteries MX-900, MX-450, MX-350

Last Modified on 07/07/2022 11:22 am EDT

Symptom:

Replaced batteries in the remote and **lost** the programming. This can occur in the **MX-350, MX-450** and **MX-900**. If this happens please follow the steps below:

Solution:

Remove all the batteries from the remote and **let it sit** for at a minimum of **five (5) minutes**. After five (5) minutes, replace the batteries. Programming "**should**" be restored. If the programming is not restored, repeat the procedure and let sit for a minimum of ten (10) minutes. If the error is still occurring, please contact URC Customer Service.

as

URC