Using the Bond Bridge with Automate Pulse 2 Shades

Using the Bond Bridge with Automate Pulse 2 Shades

This article details additional steps to include *additional* information required to be entered into the URC 'parameters' (Step #7 Properties Manager>Module Parameters) for the proper operation of the Chowmain URC Bond Bridge module when using the Automate Pulse 2 shades.

Note: This information is only supplemental to the information found in the Chowmain module integration guide. Please visit their website to view the complete module integration guide.

Using the Bond Bridge with Automate Pulse 2 Shades

In Step #7 Properties Manager>Module Parameters, this box **must** include the **LICENSE** (purchased from Chowmain), **PIN** (physically printed on Bond Bridge label), and **ACCOUNT** (located in Bond app) for the Bond module to work.
If you view the linked integration guide from Chowmain (page 9/10), you will see many examples of data that can be entered (Fan/Flame/etc.), but these three *additional* parameters are mandatory for proper operation.

(Do not use spaces)
LICENSE=XXXXXXXXXXXXXX
PIN=XXXX
ACCOUNT=XXXXXXXXXXXXXXX

Link to TC3 file and integration guide from Chowmain Software:

https://drivercentral.io/platforms/urc-drivers/bond-bridge/

Additional Information & Resources:

Link to TC3 file and integration guide from Chowmain Software:

https://drivercentral.io/platforms/urc-drivers/bond-bridge/

To learn more about Accelerator 3 configuration and programming, please see the Accelerator 3 online **Programming Guide**.