## How to Adjust the High DPI Settings When Using a 4K or Hi-Resolution Screen

Last Modified on 07/21/2025 9:10 am EDT

## How to Adjust the High DPI Settings When Using a 4K or Hi-Resolution Screen

It is possible when using a 4K or high-resolution display or laptop, you may need to adjust the High DPI scaling for best performance when using and viewing the URC Accelerator 1, 2 & 3, TC Flex 2 and Complete Control Program programs.

This article details the steps required to adjust you laptop or PC for this situation. *Note: This articles details a Windows 10 OS installation and Accelerator 3. Accelerator 1 & 2 are very similiar with different file paths and shortcuts, etc.* 

## Step #1:

Navigate to: *C:\Program Files (x86)\Universal Remote Control, Inc\URC Accelerator 3* as shown below:

(or...*URC Accelerator 2/Total Control Flex 2/Complete Control Program*. This file path may vary based on the URC program you need to adjust).

Alternately, you can also right-click on the desktop shortcut for the appropriate URC program. This shortcut is usually on your PC desktop after a standard installation.

is PC > OS (C:) > Program Files (x86) > Universal Remote Control, Inc > URC Accelerator 3				
Name	Date modified	Туре	Size	
BaseStations	2/10/2021 9:55 AM	File folder		
Bin	2/10/2021 9:55 AM	File folder		
Clients	2/10/2021 9:56 AM	File folder		
Devices	2/10/2021 9:56 AM	File folder		
- Download	2/10/2021 9:56 AM	File folder		
DrvModule	2/10/2021 9:56 AM	File folder		
Fonts	2/10/2021 9:56 AM	File folder		
Help	2/10/2021 9:56 AM	File folder		
Info	2/10/2021 9:56 AM	File folder		
styles	2/10/2021 9:56 AM	File folder		
System	2/10/2021 9:56 AM	File folder		
SysUI	2/10/2021 9:56 AM	File folder		
Tools	2/10/2021 9:56 AM	File folder		
TwoWay	3/24/2021 12:07 PM	File folder		
Usb	2/10/2021 9:56 AM	File folder		
CCS.info	5/13/2021 10:07 AM	INFO File	0 KE	
ccs_env	6/3/2021 2:33 PM	DAT File	2 KE	
🔊 uninctall	2/4/2021 5:14 DM	Application	06 K.	
URC Accelerator 3	2/10/2021 9:56 AM	Shortcut	3 KB	
	3/10/2021 3.37 AM	Application	307 KD	
🐺 URCSystem	3/24/2021 12:06 PM	Application	87 KB	

Step #2:

Right click on the **URC Accelerator 3** shortcut (or the appropriate URC program shortcut) as shown below:

URC Ace		1 0.55 A
	<u>O</u> pen	
	Move to OneDrive	
	Scan with ESET Internet Security	
	Advanced options	>
	🝐 Google Drive	>
	Open file locat <u>i</u> on	
	💎 Run as <u>a</u> dministrator	
	Share with Skype	
	Troubleshoot compatibility	
	Pin to Start	
	Unpin from tas <u>k</u> bar	
	💓 Scan with Malwarebytes	
	Restore previous <u>v</u> ersions	
	Se <u>n</u> d to	5
	Cut	
	<u>С</u> ору	
	Create <u>s</u> hortcut	
	<u>D</u> elete	
	💎 Rena <u>m</u> e	
	P <u>r</u> operties	



WRC Accelerator	3 Properties	×				
Security	Details	Previous Versions				
General	Shortcut	Compatibility				
If this program isn't w try running the comp	vorking correctly on atibility troubleshoot	this version of Windows, er.				
Run compatibility	roubleshooter					
How do I choose co	mpatibility settings m	nanually?				
- Compatibility mode						
Run this progra	am in compatibility m	ode for:				
14/:- d						
vvindows 8		~				
Settings	r mode					
8-bit (256) color	~					
Run in 640 x 4	80 screen resolution					
Disable fullscre	Disable fullscreen optimizations					
Run this progra	Run this program as an administrator					
Register this program for restart						
Change hig	Change high DPI settings					
Change settir	ngs for all users					
	ОК	Cancel Apply				

Step #4:

Check the box for: **Override high DPI scaling behavior.**..

In the drop down for: Scaling Performed By: choose Application, System or System (Enhanced). In most cases, System (Enhanced) yields the best results but this may require some experimentation depending on your specific system configuration (see image below):

URC Accelerator 3 Properties	×
Choose the high DPI settings for this program.	
Program DPI	
Use this setting to fix scaling problems for this pro instead of the one in Settings Open Advanced scaling settings	gram
A program might look blurry if the DPI for your main of changes after you sign in to Windows. Windows can this scaling problem for this program by using the DPI set for your main display when you open this program	isplay ry to fix that's n.
Use the DPI that's set for my main display when	
I signed in to Windows $\qquad \qquad \lor$	
Learn more	
High DPI scaling override ☐ Override high DPI scaling behavior. Scaling performed by:	
System (Enhanced)	
ОК	Cancel

## Additional Information & Resources:

Please refer to this article on How to Adjust Accelerator Options in Accelerator 3.