MRX-10 Not Responding or Undiscoverable

Last Modified on 05/12/2016 12:22 pm EDT

How to troubleshoot an MRX-10 that will not discover or respond

If the MRX-10 is not responding, do a **soft reset** by pressing the reset button for 2 seconds.

If there is still a communication error and/or you cannot download to it, do the following:

1. Do a **factory reset** of the unit by pressing reset button for 35 seconds (white light flickers on front panel).

2. Rediscover the MRX-10 in step 6, URC Device, and download your file twice (first download is to update the firmware and the second is for the file).

Room	Device	Mac Address	IP Ac	Idress	Туре		Refresh	Discovered:	Mac Ac
Theater	DMS-AV	00:1F:B8:13:01:0F	192,1	.68.4.51	DHCP				
Theater	MRX-10 Master	00:1F:B8:05:03:F0	192.168.4.125		DHCP		Assign	ļ	
Theater	DMS-1200	00:1F:B8:09:0D:65	192.1	.68.4.161	DHCP				
Theater	TRC-1280	00:00:00:00:00:00			DHCP				
Theater	MRX-20	00:00:00:00:00:00			DHCP				
Theater	PSX-2	00:1F:B8:10:18:60	192.168.4.139 192.168.4.138 192.168.4.122		VIEW		Pairing		
Theater	SNP-1	00:1F:B8:06:06:DA			DHCP				
Theater	MRX-4IR	00:1F:B8:14:05:20			DHCP				
Theater	TKP-7000	00:00:00:00:00:00			DHCP				
Theater	SNP-2	00:1F:B8:1A:02:8D	192.168.4.128		DHCP				
Theater	TRF-ZW1	00:0E:8F:9B:29:34	192.168.4.92		VIEW				
Theater	MRX-10	00:00:00:00:00:00	192.168.4.50		DHCP				
Theater	TRC-1080	00:1F:B8:20:FF:FD			DHCP				
TL L	MDV 00	00.00.00.00.00.00			DU/D			4	
iscover via M	RX-10								
Room	Device	Address		Version			Refresh	Discovered:	Addres
Theater	THZ-100	00:00:00:00:00:00:00:00		CHECK	HECK			1	
Master Be	e TRC-780 00:00:00:00:00:00:00 CHEC		CHECK			Assign	J		

3. Be sure your laptop is hardwired, firewall and antivirus are not enabled, and that you have opened the Accelerator program as administrator (by right clicking on the accelerator icon and choosing run as administrator).

4. Check the network settings in step 6, Lan & Wifi, part 1 Lan Network Info. We recommend using Google DNS for the preferred DNS and Alternate DNS; 8.8.8.8 and 8.8.4.4.

If you require any additional information or have any questions, please do not hesitate to contact our **technical support** team at **914-835-4484**.